

Touch Screen Operator Interface Panel

This guide gives details of all buttons/fields/functions that are available within the standard machine software. Some functions will only appear under certain conditions and/or are optional. Please check the full specification of machine supplied.


MAIN / TITLE SCREEN

This screen is displayed at power up. Tap screen to go to cutting screen



Pressing the menu button will switch the display to the Directory Screen.

DIRECTORY SCREEN



Press left hand side arrow buttons to select


1, **Main Controls**, Cut length, cut mode & linespeed adjustment

2, **Tools**, Blade speed blade type selection

3, **Setup**, Scale factor and blade datum, use passwords = maint & 2706 to enter

3, **Security**, Password protected, Gillard engineer only

SAFETY WARNING SCREEN




Indicates a guard is open, once all guarding is in place and safety circuit is reset screen will change back and display cut length adjustment area.


CUTTING SCREEN

This is the normal operator screen.

All "Normal" cutting can be controlled from this screen.




Caterpillar Stop/Start



Caterpillar Belt Speed Controls


To start Caterpillar belts press the large green button and it will start the caterpillar belts. As an indication the button will turn red and green arrows will rotate to indicate movement.

Cutter Stop/Start



To start Cutter cycle press the large green button and it will start the knife motor. Cutting mode is dependant on cut mode switch, see below. As an indication the button will turn red and green arrows will rotate to indicate movement.

Manual cut push button



When pressed completes one manual cut. Note only operates when machine is out of cutting cycle.

Length adjustment




Adjusts the length in cutting mode. Tap numbers to adjust or for small adjustments use arrow up/down buttons

Line speed length adjustment



Adjusts the caterpillar belt speed calibrated in 0.1 Metres per minute. Tap figure to display panel and adjust or for small adjustments use arrow up/down buttons

TOOLS SCREEN




Cutter Power



Adjust blade power in on demand mode. 100% = 2000 RPM.

Note, Has no effect in speed-cut mode

SET-UP SCREEN



This screen is password protected, user = maint, password = 2706

Length Scaling



Adjusts scaling factor to adjust entered cut length on HMI and actual length. Factory set

Single blade datum



Adjusts blade datum (stop position) in single blade mode. Factory set to 180' from cut point