



2.6 Digital Interfaces

2.6.1 Service Interface - COM1 (RS232)

Standard

Functions:

- Supporting all diagnosis and setup tasks
- Connection to your PC is made with the SSD Drives communication cable KnPC/D
- Communication is made via the SSD Drives operating program (EASYRIDER® Windows - Software)

| Com 1 RS232 | | Function drive side | | RS232 PC side | |
|--------------------|-----|--|--|---------------|--|
| | PIN | | | PIN | |
| 4-pin modular jack | |  | | |  |
| | | | | | |
| RXD | 1 | Receive serial data | | 3 | TXD |
| TXD | 2 | Transmit serial data | | 2 | RXD |
| | 3 | do not connect | | | |
| GND | 4 | GND | | 5 | GND |